

TurnPro™

DEPTH MARKING TOOLS

The TurnPro Depth Marking Tool helps the installer to be sure that the tubing is bottomed properly on the shoulder inside of the tube fitting body.

Part Number	Description	List Price
ITS4DMT	1/4" Depth Marking Tool	\$12.10
ITS6DMT	3/8" Depth Marking Tool	\$12.10
ITS8DMT	1/2" Depth Marking Tool	\$12.10
ITSM6DMT	6mm Depth Marking Tool	\$12.10
ITSM10DMT	10mm Depth Marking Tool	\$12.10
ITSM12DMT	12mm Depth Marking Tool	\$12.10



DEPTH MARKING TOOL INSTRUCTIONS

- ▶ Insert tubing that has been cleanly cut and deburred into the opening of the Depth Marking Tool until the tubing is bottomed out against the shoulder of the tool.
- ▶ Using a felt tip permanent marker mark the tubing at the top of the Depth Marking Tool.
- ▶ Remove the tubing from the Depth Marking Tool. Insert it into the tube fitting until it bottoms out against the shoulder of the tube fitting.
- ▶ Rotate the fitting nut until it is finger tight. If the mark on the tubing can be seen above the nut the tubing is not fully inserted into the fitting.

SSP · 8250 BOYLE PARKWAY · TWINSBURG, OH 44087 · +1.330.425.4250

100% Made in the U.S.A.

mySSPusa.com/TurnPro

SSP